PARTS LIST

for

Whirlpool CORPORATION

UNDERCOUNTER DISHWASHER

MODEL DU8770XY1

Almond/Black

FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS

Whirlpool CORPORATION
Benton Harbor, Michigan.

5−92 Litho In U.S.A.

© 1992 WHIRLPOOL CORPORATION

Part No. 3370197

FRAME AND CONSOLE PARTS

For Model: DU8770XY1



Illus. No.	Part No.	DESCRIPTION
1	3371834	Console (Includes Item 2)
2	3372125	Insert, Console
3	3369564	Switch
4	3368997	Follower, Cam
5	3369358	Timer
6	3369415	Cam
7	304231	Screw, 8−18 x 1/2 (5)
8	3368900	Door Frame
9	3368953	Bolt, Latch
10	3368954	Lever, Latch
11	3369325	Switch, (2)
12	3368955	Pin, Switch (2)
13	3372252	Harness and Protector (Includes Item 14)
14	3368977	Elbow, Harness
15	9412221	Screw, 8−32 x 1/4
16	3369192	Cover Timer
17	3368998	Knob, Timer
18	3368979	Spacer, Corrugated
19	3369516 †	Panel, Front (Almond/Black)
20	3370441	Retainer, Panel
21	3369318	Light Assembly
22	3369598	Trim, Console
23	3369592	Trim (2)
24	3369569	Insert, Switch
25	98997	Clip, Harness

† Refer To Dishwasher Replacement Panel Parts List No. 675345.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INNER DOOR PARTS

For Model: DU8770XY1



Illus. No.	Part No.	DESCRIPTION
1	3371481	Inner Door (Also Order Latch Door Kit 676413)
2	3369060	Latch, Detergent Dispenser
3	3369061	Snap, Detergent Dispenser
4	3369055	Actuator Assembly
5	3368967	Wet Agent, Dispenser
6	3369000	Draw Bar (Upper Dispenser)
7	3369602	Draw Bar (Lower Dispenser)
8	3368999	Spring (Draw Bar)
9	3368981	Lid Assembly
10	300106	Spring, Lid
11	300115	Pin (Lid Hinge)
12	3369603	Screen, Vent
13	3369512	Wet−Agent Cap Assembly
14	3369155	Seal (Wet−Cap)
15	3369051	Screw (8)
16	3371569	Cover, Drip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS

For Model: DU8770XY1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS

For Model: DU8770XY1

Illus. No.	Part No.	DESCRIPTION
1	3370851	Tub & Support Assembly
2	3369078	Tub, Wheel Assembly (8)
3	3368932	Runner (2)
4	302849	Leveler (2)
5	3370389	Screw, Shoulder (2)
6	302819	Wheel (2)
7	343641	Screw, 10−16 x 1/2 (4)
8	3372030	Plate, Latch
9	3372029	Screw
10	3368994	Gasket
11	3372412	Retainer, Access Panel
12	3369052	Deflector (2)
13	3369416	Heater
14	717273	Washer, Rubber (2)
15	3369073	Nut (2) (Heater Terminal)
16	3371817	Water Valve
17	304392	Screw, 8−18 x 1/2
18	3369777	Thermostat, Hi−Limit
19	3370782	Thermostat
20	301958	Clamp
22	3369775	Retainer, Shield
23	3370225	Screw
24	3369447	Relay
25	304231	Screw, 8−18 x 1/2
26	3369617	Sound Shield
27	3368983	Shield, Harness
28	3370939	Spring & Bearing Assembly (2)
29	3369048	Housing, Float Switch
30	3369067	Switch, Float
31	3369049	Cover, Switch Housing
32	3371282	Float
33	717488	Nut
34	3368942	Toe Panel
35	3369193	Panel, Access
36	302868	Screw, 8−18 x 1/2 (4)
37	3369414	Hose, Inlet
38	3368781	Drain Hose
40	3369771	Sound Shield
41	3370292	Terminal Box
42	300068	Cover Assembly, Terminal Box
43	3369527	† Access Panel (Almond/Black)
44	3369526	Spacer, Corrugated
45	3369531	Extension
46	3369593	Trim, Side (2)
47	3369588	Trim, Bottom
48	3367052	Hose Clamp
49	3370555	Bracket, Thermostat
50	359625	Screw
51	3370942	Sound Shield
52	3368987	Support, Heater
53	3371578	Screw, 8−32 x 1/2
54	3371579	Nut, 8−32
55	3370307	Strain Relief
56	3369138	Screw, 8−18

† Refer To Dishwasher Replacement Panel Parts List No. 675345.

PUMP AND MOTOR PARTS

For Model: DU8770XY1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PUMP AND MOTOR PARTS

For Model: DU8770XY1

Illus. No.	Part No.	DESCRIPTION
1	302720	Plate, Perforated (Includes Item 5) (Also Order Item 30) See Note A.
2	3367173	Base, Inlet (Includes Items 1 & 5) (Also Order Item 30) See Note A.
3	303573	Screw, 8−18 x 5/8
4	302710	Seal, Inlet Base
5	302709	Ball, Check
6	95080	"O" Ring
7	302721	Cover, Valve
8	302738	Valve Stem Kit (Includes Items 12, 13 & 22) See Note A.
9	303883	Separator Assembly (Includes Items 12, 13 & 22) See Note A.
10	302717	Screw, 8−18 x 1−5/8 (4)
11	303510	Impeller, Wash (Includes Items 12 & 13)
12	3371152	Screw & Seal, 10−32 x 3/4
13	302711	Seal, Pump Outlet
14	3369478	Outlet, Pump (Includes Item 13)
15	3369482	Check Valve (Includes Item 6)
16	717000	Gasket, Pump
17	3369475	Pump & Motor Assembly (Includes Item 16)
18	302707	Bushing, Grind
19	302718	Chopper Kit (Also Order Item 30) See Note A.
20	302705	Sleeve, Drain Impeller
21	718258	Screw, 8−18 x 5/8
22	302704	Seal, Drain Cover
23	302723	Cover, Drain (Also Order Item 30) See Note A.
24	303539	Impeller, Drain Kit (Also Order Item 30) See Note A.
25	3367204	Base, Pump (Includes Item 24) (Also Order Item 30) See Note A.
26	3367197	Support, Pump Mounting (4)
27	3368270	Slinger (See Note A.)
28	3369472	Motor (Includes Item 27) (Also Order Item 30) (For Electrical Connector Only, See Wiring Harness Page.) See Note A.
29	3369331	Screw (4)
30	675505	Pump Seal Kit (Includes Items 4, 12, 13 & 22)
31	303918	Tool, Pump Centering

NOTE A:
Pump Centering Tool Required For Pump Re−Assembling− Order Item 31.

DISHRACK PARTS

For Model: DU8770XY1



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISHRACK PARTS

For Model: DU8770XY1

Illus. No.	Part No.	DESCRIPTION
1	303722	Clip
2	3368290	Support, Arm
3	3368300	Spray Arm, Upper
4	3368006	Bumper (2)
5	300848	Tower, Pressure
6	3369509	Wheel & Transport Assembly (4)
7	3371374	Dishrack, Lower (Includes Items 4 & 6)
9	3369488	Silverware Basket Assembly
10	3369485	Cover, Basket
11	3369046	Stop, Track (2)
12	3369071	Track
13	301077	Screw
14	3369980	Housing, Adjuster (2)
15	3369981	Worm (2)
16	3369979	Plate, Mtg. (2) (Adjuster)
17	300845	End Cap
18	3369911	Dishrack, Upper
19	717528	Trim, Basket
20	300086	Handle, Basket
21		Arm Assembly (Includes Item 15)
	3369977	Right Side
	3369973	Left Side
22	3369347	Sprayarm, Lower
23	3367910	Cap, Nozzle
24	719576	Bearing, Nozzle

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH−UP (1/2oz.)

72017	White
72107	Almond
72112	Black

PAINT, PRESSURIZED SPRAY (13 oz.)

350956	Almond
285006	Superior Black
206922	Primer (White)
350941	Leveler (Thinner)

PAINT, TOUCH−UP (1 qt.)

978883	Almond (Uncut)
799340	Black (Uncut)

ACCESSORY PARTS

Side Panel Kits:

4317925	White
4317926	Avocado
4317927	Gold
4317929	Almond
4317930	Toast
4317931	Platinum

DISHRACK REPAIR

675576	Vinyl Touch−Up (Blue)
675677	Tine Tip Repair Kit (Blue−− Enough For Two Complete Dishracks)
676453	Vinyl Touch−Up (White)
675679	Tine Tip Repair Kit (White−− Enough For Two Complete Dishracks)
676455	Vinyl Touch−Up (Grey)
676458	Tine Tip Repair Kit (Grey−− Enough For Two Complete Dishracks)

LITERATURE PARTS

LIT3369093	Instructions, Installation
LIT3367007	Instructions, Installation (Supplement) (Locating Your Water Supply)
LIT3370043	Energy Guide
LIT3369105	Guide, Use & Care
LIT3370467	Wiring Diagram
LIT3370197	Parts List

MISCELLANEOUS PARTS



Illus. No.	Part No.	DESCRIPTION
1	3369816	Miscellaneous Parts Bag (Includes 2 Screws & 2 Hose Clamps)